Quick start guide

EL51109
DECT 6.0 cordless telephone with caller ID/call waiting

Installation

Install the telephone base close to a telephone jack and a power outlet not controlled by a wall switch. For optimum range and better reception, place the telephone base in a central and open location.

If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone line, you must install a DSL filter between the telephone line cord and the telephone wall jack (see the following page). The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Your product may be shipped with a protective sticker covering the handset or telephone base display - remove it before use.

For customer service or product information, visit our website at **www.telephones.att.com** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Avoid placing the telephone base too close to:

- Communication devices such as: television sets, VCRs, or other cordless telephones.
- Excessive heat sources.
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting.
- Excessive dust sources such as a workshop or garage.
- Excessive moisture.
- Extremely low temperature.
- Mechanical vibration or shock such as on top of the washing machine or workbench.

Battery installation & charging

Install the battery as shown on the next page. After installing the battery, you might be able to make and receive short calls. For best performance, charge the handset for at least 16 hours before use. When not in use, place the handset in the telephone base.

If the battery is depleted, it may take approximately ten minutes to charge the handset before it shows **LOW BATTERY**. The screen continues to display **LOW BATTERY** until the battery has charged for approximately one hour; the backlight on the handset disables when in low battery mode.

Battery indicators	Battery status	Action
The screen is blank.	Battery has no charge and the handset cannot be used.	Charge until the screen shows **LOW BATTERY** (about 10 minutes).
The screen shows **PLACE IN CHARGER** and ▯ flashes.	Battery has very little charge, the handset cannot be used.	Charge until the screen shows **LOW BATTERY** (about four minutes).
The screen shows **LOW BATTERY**, ▯ flashes, and you hear four short beeps every minute.	Battery has enough charge to be used for a short time.	Charge until the screen shows **HANDSET** (about one hour).
The screen shows **HANDSET**.	Battery is charged.	To keep the battery charged, place it in the telephone base when not in use.

Battery installation & charging

Step 1
Plug battery connector securely into the socket inside the handset battery compartment, matching the color-coded label. Insert the supplied battery with the label **THIS SIDE UP** facing up as indicated.

Step 2
Align the cover flat against the battery compartment, then slide it upwards until it clicks into place.

Step 3
Charge the handset by placing it face up in the telephone base. The **CHARGE** light is on when charging.

To replace the battery, press the tab and slide the battery compartment cover downwards. Lift out the old battery and disconnect it from the handset. Follow the instructions above to install and charge the new battery.

IMPORTANT INFORMATION

Use only the power adapter supplied with this product. To order a replacement power adapter, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Telephone base installation

Install the telephone as shown below. The telephone base is ready for table use.

5. Plug the other end of the telephone line cord into a telephone jack or a DSL filter.

4. Plug the large end of an AC power adapter into an AC power outlet not controlled by a wall switch.

3. Route the power adapter cord through the slot.



1. Plug one end of the telephone line cord into the telephone jack on the bottom of the telephone base.

2. Plug the small end of the power adapter into the power jack on the bottom of the telephone base.

IMPORTANT INFORMATION

1. Use only the power adapter supplied with this product. To order a replacement power adapter, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.
2. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

Quick reference guide - handset



CHARGE light

The charge light is on when the handset is charging.

▲DIR/VOLUME

Press **DIR▲** to show directory entries when the phone is not in use.

Press to scroll up while in menus. Press **▲VOLUME** to increase the volume level during a call.

REDIAL/PAUSE

Press repeatedly to view the last five numbers dialed. While entering numbers, press and hold to insert a dialing pause.

PHONE/FLASH

Press to make or answer a call.

During a call, press to answer an incoming call when you receive a call waiting alert.

1

While reviewing a call log entry, press repeatedly to add or remove 1 in front of the telephone number before dialing or saving it in the directory.

SPEAKER

Press to switch between speakerphone and handset.

▼CID/VOLUME

Press **▼CID** to show caller ID information when the phone is not in use.

Press to scroll down while in menus. Press **▼VOLUME** to decrease the volume level during a call.

MENU/SELECT

Press to display the menu. Once in the menu, press to select an item or save an entry or setting.

OFF/CLEAR

Press and hold while the telephone is not in use to erase the missed calls indicator.

During a call, press to hang up.

While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display.

MUTE

During a call, press to mute microphone.

#

Press repeatedly to display other dialing options when reviewing a call log entry.

DELETE

While reviewing the caller ID history, or the directory, or the redial memory, press to delete an individual entry.

While predialing, press to delete digits.

Main menu

> Shows a highlighted item

Main menu

DIRECTORY
CALL LOG
RINGER VOLUME
RINGER TONE
KEY TONE
LCD LANGUAGE
SET DATE/TIME
CLR VOICEMAIL
HOME AREA CODE

Using menus

Press ▲**DIR** or ▼**CIR** to scroll through menu items.

Press **MENU/SELECT** to select or modify a highlighted item.

Press **OFF/CLEAR** to cancel an operation, back up to the previous menu, or exit the menu display.

IN USE indicator

On when the handset is in use.

Flashes when another telephone is in use on the same line.

Flashes quickly when there is an incoming call.



VOICEMAIL indicator

Flashes when you have new voicemail. Voicemail service is offered by your local telephone company.

HANDSET LOCATOR

Press to make handset beeps so you can locate them.

www.telephones.att.com

© 2009 Advanced American Telephones. All rights reserved.
AT&T and the AT&T logo are trademarks of AT&T Intellectual Property II, L.P. d/b/a
AT&T Intellectual Property licensed to Advanced American Telephones,
San Antonio, TX 78219. Printed in China. Issue 2 AT&T 01/09.
96-006928-010-100